Locating Fan location by FAN Number on SGI FUEL Workstations

Published 07/01/2008

Symptom(s):

Locating Fan location by FAN Number on SGI FUEL Workstations
Problem locating defective FAN on SGI FUEL

Fact(s):

SGI Fuel
SGI FUEL and Fan Numbers

SGI Solution:

Below is a "fan-to-part number" listing:

Fan #	Description	Part Number	Info*
FAN 0	EXHAUST	013-3474-001	
FAN 1	HD	013-3475-001	
FAN 2	PCI	013-3473-001	* (upper fan of the three fans)
FAN 3	XIO 1	013-3473-001	* (lower front fan of the three fans)
FAN 4	XIO 2	013-3473-001	* (lower rear fan of the three fans)
FAN 5	PS	060-0140-005	

Illustrations of Fan locations "By Name" are located in the following external URL:

http://techpubs.sgi.com/library/tpl/cgi-bin/getdoc.cgi/srch8@fuel_fan/hdwr/bks/SGI_EndUser/books/Fuel_UG/sgi_html/ch04.html#LE56983-PARENT

Answers others found helpful

- Fuel - Blinking white LED, system power cycles or reboots on its own.
- Decode lightbar status (diagnostic LEDs) for a non-booting Fuel
- How-to lock the Ethernet Interface to 100mbit/full duplex on a Fuel

Additional Details

Creation Date	06/18/2008 11:33 AM
Last modification	11/18/2016 03:36 PM
Published Date	07/01/2008
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • Technical Solution